SUPPLEMENT

Emerson®

SERVICE MANUAL

This service manual shows only the differences between the model EWD2004 and the original model EWD2204. All other information is described in the service manual of the model EWD2204.

DVD PLAYER & VIDEO CASSETTE RECORDER

EWD2004



Different parts from original model (EWD2204)

Ref.No.	Description	Parts No.
Mechanical Parts		
A1X	FRONT ASSEMBLY H9612UD	1VM220173
A10⚠	RATING LABEL(2 FACTORY) H9612UD or	----------
⚠	RATING LABEL(3 FACTORY) H9612UD	----------
A14	LABEL, BAR CODE HB400UD or	----------
	BARCODE LABEL H9612UD	----------
S1	GIFT BOX H9612UD	1VM320381
X20⚠	OWNER'S MANUAL H9612UD	1VMN20189
Electrical Parts		
	DVD MAIN CBA UNIT	N79FSHUP